

REPLACING WORLD SWITCH

1. REMOVE SWITCH HOUSING COVER FROM TIP PLATE (6 SCREWS).
2. NOTE LOCATION OF SENSORS IN SWITCH HOUSING. NOTE ORIENTATION OF BULLSEYE OR CIRCLE INDICATOR ON SENSOR. (TAKE PHOTO FOR REFERENCE)
3. REMOVE WORLD SWITCH FASTENER. REMOVE RUBBER STRIP (IF APPLICABLE) THAT HOLDS WIRES IN PLACE. REMOVE SWITCH AND SENSOR ASSEMBLIES.
4. REMOVE SENSOR PINS FROM SENSORS AND SPACERS.
5. INSTALL NEW SENSORS TO SPACERS WITH PINS.
6. INSTALL NEW SENSORS & SWITCH TO PROPER LOCATION AND ORIENTATION. SECURE LOOSE WIRES INTO SWITCH HOUSING WITH RUBBER STRIP, IF APPLICABLE.
7. INSTALL SWITCH HOUSING COVER TO UNIT TIP PLATE WITH SCREWS (6).

IMPORTANT: NOTE LOCATION OF SENSORS IN SWITCH HOUSING. NOTE ORIENTATION OF BULLSEYE OR CIRCLE INDICATOR ON SENSOR.

